

Connect profiles with a slot




# Connect a glass profile

901 40 0350

Where to use the manual bolt with the small hammer nut:

- Connection between glass profile & lightbox 124D
- Connection between glass profile & double deck, beConstruct, pop-out




# Connect a glass profile to a glass profile

901 40 0370

Where to use a bolt with the small hammer nut:

- Connection between a glass profile and a glass profile
- Connection between a glass profile and a lightbox 124S/186D



# Connect a glass profile to a glass profile

901 40 0370 SET

Where to use a bolt with the small hammer nut:

- Connection between a glass profile and a glass profile
- Connection between a glass profile and a lightbox 124S/186D

901 40 0370 SET (= SET OF 10 PCS)





Connect a lightbox 124D

901 40 0360

Where to use the manual bolt with the small hammer nut:

- Connection between lightbox 124D & double deck, beConstruct

#### 901400360





# Connect corner profile


171 79 12 08 29

Where to use the manual bolt without the small hammer nut:

- Connection between corner profile & glass profile
- Connection between corner profile & Lightbox 124D/124S/186D













**GLASS PROFILE** 



**LIGHTBOX 124S/186D** 




## **Universal SET** for slots

901 40 0380 SET

### 901 40 0380 SET (= UNIVERSAL SET TO MAKE CONNECTIONS WITH SLOTS)



#### 901 40 0380 SET MANUAL








#### Connect b62

901 2048 0066 E 901 2059 M8 Where to use the manual bolt with the small hammer nut:

- Connection between b62 & glass profile
- Connection between b62 & lightbox 124D
- Connection between b62 & doubledeck, beConstruct, pop-out
- Connection between b62 & corner profile



# Connect a lightbox 124D

171 79 12 08 29 901 2059 M8 Where to use the manual bolt with the hammer nut:

- Connection between lightbox 124D & lightbox 124D

