

beCAD® Web – Keyboard Hotkeys

Version | 25/06/2026

COMPONENT OPTIONS		
	<i>TOOL</i>	<i>HOTKEY</i>
	<u>M</u> OVE	M
	* <u>R</u> OTATION	R
	<u>D</u> UPLICATE	D
	<u>S</u> CALE	S
	<u>S</u> NAPPING (POINT-TO-POINT)	N
	<u>S</u> NAPPING (SURFACE-TO-SURFACE)	N (2X)

EDIT + SELECT	
<i>FUNCTION</i>	<i>HOTKEY</i>
COPY	CTRL + C
PASTE	CTRL + V
UNDO LAST	CTRL + Z
DELETE	DELETE FN + BACKSPACE
CLEAR SELECTION	ESC

ADVANCED	
<i>FUNCTION</i>	<i>HOTKEY</i>
COPY SELECTION + MOVE	CTRL + M
COPY SELECTION + ROTATE	CTRL + R
**ROTATE SELECTION 90° (Z-AXIS)	Q
**ROTATE SELECTION 90° (X-AXIS)	SHIFT + Q
**ROTATE SELECTION 90° (Y-AXIS)	ALT + Q
RECTANGULAR SELECTION	W
ADD TO RECTANGULAR SELECTION	W + CTRL (hold)
REMOVE FROM RECTANGULAR SELECTION	W + ALT (hold)

OTHER	
<i>FUNCTION</i>	<i>HOTKEY</i>
SEARCH LIBRARY	CTRL + K

Note: beCAD® Web functions with the ** indicator can use the 'CTRL' key toggle feature.

- ◆ Holding 'CTRL' while using the Rotation tool will rotate the component by 5° increments
- ◆ Adding 'CTRL' to the advanced rotation functions will rotate selection by 45° instead of 90°